


CABLE DIAGRAM

Should your cable become disengaged, follow the numbers, in sequence, on the diagram below to recable your projector. (NOTE: Cable wraps around center pulley one time.)



DB 300
CABLING DIAGRAM