

IMPORTANT SAFEGUARDS

When using your projection equipment, basic safety precautions should always be followed, including the following:

1. Read and understand all instructions.
2. Close supervision is necessary when used by or near children. Do not leave unattended while in use.
3. Take care not to touch hot parts.
4. Do not operate with a damaged cord or if the projector has been dropped or damaged — until it has been examined by a qualified electrician.
5. If an extension cord is necessary, a cord with a suitable current rating should be used. Cords rated for less amperage than the projector may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
6. Always unplug from electrical outlet when not in use. Never yank cord to pull plug from outlet. Grasp plug and pull to disconnect.
7. Let projector cool completely before putting away. Loop cord loosely around projector when storing.
8. Should the projector sustain water damage, do not use until inspected by qualified electrician.
9. To avoid electrical shock hazard, do not disassemble this projector. Take it to a qualified electrician. Incorrect reassembly can cause electrical shock.