

DB 300 PARTS LIST

Ref.	Description	Part No.
1	Mirror	108-014
2	Lamp, 150W 110V (2 per unit)	106-006
	Lamp, 150W 220V (2 per unit)	106-013
3	Lens	107-027
4	Switch	145-114
5	View Light Assembly, 110V	200-354
	Lamp, 110V View Light	106-021
	View Light Assembly, 220/240V	200-352
	Lamp, 220/240V View Light	106-022
6	Fan Assembly	200-189
	Fan Motor, 110V	145-500
	Fan Motor, 220V	145-514
7	Retaining Ring (4 per unit)	100-291
8	Guide Rod (2 per unit)	150-496
9	Focus Handle	100-219
10	Carriage Assembly	200-182
11	Receptacle	150-612
12	Spud	150-510
13	Brake Pad	150-594
14	Column Bearing Assembly (4 per unit)	200-192
15	Negator Spring Assembly	200-254
16	Spring, Clamp (4 per unit)	102-012
17	Screw, Clamp (4 per unit)	100-012
18	Locking Knob	100-225
19	Cable Assembly	200-186
20	Power Cord	145-099
21	Screw, Hood (3 per unit)	100-231
22	Hood	150-506
23	Diffusion Glass	108-017
24	Copyboard	150-520
25	Receptacle, Electrical	145-150