

# SET-UP INSTRUCTIONS

## FOLLOW IN ORDER

1. Clamp column assembly to the edge of a sturdy drawing table or other appropriate support \*(Fig. 1).
2. Place lamp house assembly onto the cone.
3. Remove and save screws holding the cover to the lamp house base. Remove cover (Fig. 2).
4. Unfasten mirror from copyboard and install into the mirror bracket (Fig. 2).
5. Replace top and fasten with screws.

\*Note: (Fig. 1) If your table appears to be of questionable stability, it can be strengthened by the addition of a 6" length of 1" x 4" wood board between the clamp screw and the underside of your board.




Fig. 1